

Special protection of : an laboratory test facility



- The risk of fire in fume cupboards is often underestimated. Carrying out tests with all kinds of products can result in dangerous situations and fire.
- Therefore, the protection of these items is certainly recommended.
- Different extinguishing media can be chosen according to the products used.
- An autonomous extinguishing system with corresponding spray nozzles is installed per fume cupboard. Detection happens with a heat-sensitive polymer pipe. In the event of fire, the pipe will burst and activate the extinguishing system. Thanks to this fast detection, damage inside the cabinet is reduced to a minimum.
-



PROTECTING TODAY'S FUTURE



PROTECTING TODAY'S FUTURE

Somati Services nv – Industrielaan 19 – BE-9320 Erembodegem (Aalst) – tel +32 (0)53 85 22 22 – fax +32 (0)53 85 22 21 – www.somati.com – info@somati.be

N.B.: Wij maken alle voorbehoud voor eventuele wijzigingen ingevolge technische verbeteringen die steeds kunnen voorkomen.

En fonction des améliorations techniques éventuelles, nous nous réservons le droit d'apporter les modifications requises ou imposées.

We reserve the right to make changes in accordance with any technical improvements introduced.